



↙  
Illuminated  
selector switch  
2 positions

↙  
Illuminated  
selector switch  
2 positions

Illuminated  
button  
spring-return

Illuminated  
button  
spring-return

Illuminated  
button  
spring-return

Non-illuminated  
button  
spring-return

	Contacts	Diagram
Device 1	1NO	A1 — A2 A6 — A3 LED
Device 2	1NO	A1 — A4 A8 — A3 LED
Device 3	1NO	A1 — A7 A5 — A3 LED
Device 4	1NO	B1 — B2 B6 — B3 LED
Device 5	1NO	B1 — B4 B8 — B3 LED
Device 6	1NO	B1 — B7 B5 — B3 LED

