

DIN 4844





Vor Wartung oder Reparatur freischalten/
power off before maintenance or repair

INSTRUCTION

Industrial Hall

CE



982266.004

D180, H70

88 g



EN 12464

