



Indicator light

Indicator light

Indicator light

Indicator light

Illuminated
selector switch
2 positions
✓

Illuminated
button
spring-return

Emergency
push button

	Contacts	Diagram
Device 1	/	A2 —  — A3
Device 2	/	A6 —  — A3
Device 3	/	A12 —  — A3
Device 4	/	B2 —  — B3
Device 5	1NO	B1 —  — B5 B6 —  — B3
Device 6	1NO	B1 —  — B7 B12 —  — B3
Device 7	2NC	 — FD B8 —  — B9 B10 —  — B11

