

Illuminated selector switch
3 positions
↓

Non-illuminated button
spring-return

Non-illuminated button
spring-return






Illuminated selector switch
2 positions
↓

Illuminated button
spring-return

Non-illuminated button
spring-return

Illuminated button
spring-return

Emergency push button

	Contacts	Diagram	Connections
Device 1	2NO	A1 — A4	
		A1 — A10	
		A2 — A3	
Device 2	1NO	A1 — A5	
		A6 — A3	
		A1 — A7	
Device 3	1NO	A8 — A3	
		A1 — A9	
		A12 — A3	
Device 4	1NO	B1 — B4	
		B2 — B3	
		B1 — B5	
Device 5	1NO	B6 — B3	
		B1 — B7	
		B12 — B3	
Device 6	1NC	B1 — B7	
		B12 — B3	
		B8 — B9	
Device 7	1NO	B10 — B11	
		B8 — B9	
		B10 — B11	
Device 8	2NC	B8 — B9	
		B10 — B11	
		B8 — B9	

