


# LIVING-LIGHT

# Home / Away wireless switch



#### Use

It is equipped with 2 buttons for activating Home / Away scenarios.

Scenarios can be customized by the Home + Control app.

Surface installation with repositionable stickers (supplied) or onto a flush mounting box. Integrated LED for low battery indication.

Powered by battery 3V type CR2032 (supplied) with an autonomy of 8 years - 2 modules.

#### Standards and approvals

The under signed, BTICINO, declares that the radio-electric equipment type (N-NT-L4570CW) complies with directive 2014/53/EU.

The full text of the EU declaration of conformity is available on the following website: www.bticino.it/red

# Pesignation Cat. Nos. Home / Away wireless control, with battery. Equipped with an LED indicator (confi-guration) and a RESET button (hidden) used to return to factory settings. Repositionable self-adhesive fixings supplied. ■ N4570CW ■ L4570CW


Colours code:

 $\square$  White

Silver

Anthracite

# Dimensions (mm)



A	В	C
74	74	11

## **Technical characteristics**

# - Mechanical characteristics

Protection against impacts: IK 02

Protection against solid bodies/liquids:  $\,$  IP 20 without plate and rocker plate

#### - Material characteristics

Mechanism with grid: Fibreglass-reinforced (10%) PC

Mechanism functional cover: PC/ABS

Supporting base: fiberglass-reinforced PA (60%).

Halogen-free UV resistant

Self-extinguishing: 650°C/30 s

## - Electrical characteristics

Powered by a CR2032 - 3 V lithium battery (supplied)

Battery life: 8 years for 10 activations a day **ZigBee radio technology** frequency: 2.4 GHz to 2.4835 GHz

Wireless mesh network, self-adaptive and secure (AES 128), conforming to standard

IEEE 802.15.4 (LR-WPAN)

Power level: < 100 mW

### - Climate characteristics

Usage temperature:  $+5^{\circ}$  C to  $+45^{\circ}$  C Storage temperature:  $0^{\circ}$  C to  $+45^{\circ}$ 







# Home / Away wireless switch

# Operation

Front view



Front view without coverkey



# Legend

- 1. Control pushbutton
- 2. LED indicator: useful during installation
- 3. RESET button used to return to factory settings

# Care

Clean the surface with a cloth.

Do not use acetone, tar-removing cleaning agents or trichloroethylene.

Resistant to the following products: Hexane (EN 60669-1), methylated spirit, soapy water, diluted ammonia, bleach diluted to 10%, window-cleaning products, preimpregnated wipes.

# Caution: Always test before using special cleaning products.

The plates must not be painted.



Take care to recycle the battery appropriately.

RAEE/WEEE: bticino.com/disposal

